MODEL: 32468BH
PACKING DIAGRAM





AVAILABLE PARTS ARE:
32468SHBH (SHADE)
HARP9 (HARP)

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS LAMP SHOULD TAKE APPROXIMATELY 15 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE LAMP

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: FINIAL, RUBBER WASHER, SHADE, HARP, SOCKET ASSEMBLY, NECK, POLE, CENTER TUBE, SMALL RUBBER WASHER, GLASS TRAY, LARGE RUBBER WASHER AND BASE. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

ASSEMBLE THE LAMP

1. CAREFULLY ORGANIZE AND PLACE ALL PARTS ON A SMOOTH, FLAT SURFACE. LINE UP ALL OF THE PARTS ACCORDING TO THE ASSEMBLY DIAGRAM.
2. FEED THE CORD THROUGH THE HOLES OF LARGE RUBBER WASHER, GLASS TRAY AND SMALL RUBBER WASHER, AND THEN SLIDE THE LARGE RUBBER WASHER, GLASS TRAY AND SMALL RUBBER WASHER OVER THE NIPPLE ON TOP OF THE BASE.
3. TIE A SAFETY KNOT IN THE CORD AS SHOWN.
4. JOIN THE CONNECTORS TOGETHER, AND THEN INSERT THE CONNECTOR AND SAFETY KNOT INTO THE CENTER TUBE AS SHOWN.
5. SCREW THE CENTER TUBE TO TOP OF THE BASE.
(NOTE: TO PREVENT BREAKING THE GLASS TRAY, DO NOT OVER TIGHTEN THE CENTER TUBE ONTO THE GLASS TRAY TOP)
6. SLIDE THE POLE OVER THE CENTER TUBE.
7. SCREW THE NECK TO END OF THE CENTER TUBE.
8. TUCK AND INSERT THE EXCESS CORD INTO THE HOLE OF NECK, AND THEN SCREW THE SOCKET ASSEMBLY TO TOP OF THE NECK.
9. SQUEEZE LEGS OF THE HARP TOGETHER AND INSERT THE TWO ENDS BETWEEN THE PRONGS OF THE HARP HOLDER.
10. PLACE SHADE ONTO HARP, THEN SECURE WITH RUBBER WASHER AND FINIAL.
11. INSTALL A 150 WATT MAXIMUM MEDIUM BASE TYPE "A" 3–WAY BULB (NOT INCLUDED) INTO SOCKET.
12. PLUG THE POWER CORD INTO AN OUTLET AND TURN ON AT SWITCH.

BULB REPLACEMENT

1. BEFORE REPLACING THE BULB, BE SURE THAT THE SHADE AND BULB ARE COOL AND LAMP IS UNPLUGGED.
2. UNSCREW EXISTING BULB FROM SOCKET AND REPLACE WITH A NEW BULB. PLUG POWER SUPPLY CORD BACK INTO OUTLET.

TROUBLE SHOOTING

1. IF YOUR LAMP DOES NOT LIGHT, CHECK PLUG AT THE OUTLET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE POWER OUTLET.
2. IF LAMP STILL DOES NOT LIGHT, UNPLUG FROM OUTLET. CHECK THE BULB FOR A BROKEN FILAMENT. REPLACE BULB IF NECESSARY, PLUG IN LAMP AND TURN IT ON.
3. IF THE LAMP STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.